

# JOUNING

## PORTABLE VENTILATOR

TYPE: JPV -300  
SPEED: 2926 R.P.M.  
CAPACITY: 60 C.M.M.  
VOLTAGE: 240VOLTS  
PHASE: SINGLE  
STATIC: 42 mm/Aq  
JOUNING BLOWER CO. LTD

These instructions are for your protection and convenience. Please read them carefully since failure to follow this precaution could result in discomfort or injury. When using electrical equipment, basic safety precaution should always be followed.

**“RETURN TO SUPPLIER FOR REPAIRS”**

- Never put JPV-300 into standing water because of extreme shock hazard.
- Never allow air intake screen to be plugged.
- Never discharge flammable dry cleaning solvents or kerosene-based chemical through the air intake screens.
- Do not use in areas where flammable liquids are present.
- Never put any object in the intake screen unless the unit is unplugged and the wheel has stopped/
- Never run the machine out in the rain.
- Never store outside.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only with the correct power supply.
- Do not use with damaged cord.
- Do not unplug by the cord.
- Do not handle the plug or cord with wet hands.
- Do not put any object into the intake screen.
- Keep hair, loose clothing, fingers, and all parts of the body away from the intake screen.

**NOTE:** Do not allow any water inside the motor! If the motor becomes wet for any reason, thoroughly dry and test before using the JPV-300. Never remove the ground from the power cord, as this may result in electrical shock.

### ***INSTRUCTIONS FOR OPERATION***

Note the direction of airflow. Prior to plugging in the JPV-300, inspect the inlet and outlet screens remove any debris, which may restrict air movement. Check the on/off switch is off before turning on the power supply.